

N-2013L can use for most of smart tv, only a few

function can not match.

Simply click, point, scroll to change the channel, search for something new and more. The Magic remote

N-2013L can also be used to operate your connected

devices. Spend less time navigating confusing menus and juggling multiple remotes, and more time enjoying your

entertainment.

N-2013L is a substitute product which is without voice

function.

Instruction

A. Register the remote

1. Press the "WHEEL(OK)" about 3 seconds, LED will be light on the remote.

2. Plug the USB receiver into TV's USB port, connection

image is appeared on the screen.

3. Point the remote at the USB receiver, LED will flash

3 times and then goes off, registration is completed.

pointer is appeared on the screen.

*With a few TV sets, if there is no response when plug into a USB port, please try another USB ports.

B. About Pointer

To display the pointer on the screen again, press the POINTER KEY . You can shake the remote

slightly to the right and left to control the direction.

If you press DIRECTION KEYS (UP/DOWN/LEFT/RIGHT) while the pointer is in use, the

pointer will disappear from the screen.

(EN)

C. As a normal IR remote(Deregister the remote)

Press and hold the "HOME" and "BACK" .

KEY at the same time about 5 seconds to unpair the

remote with your TV, LED will flash 3 times and then

goes off. Magic Remote will operate like a general IR

remote control.

When registration is completed, DIRECTION KEYS

△▽▷◁ (UP/DOWN/LEFT/RIGHT), SCROLL UP, SCROLL DOWN, WHEEL(OK), Q.SETTINGS

、POINTER KEY are use RF,

but other function key still retain to use IR.

D. Method of Learning Function for STB

Those key can be learn by Set-up Box original remote

control :   

1. Press HOME and into the learning mode ,

the LED will be flashed slowly.

2. Put the receivers towards to each other, the distance

must be 2-5cm.

3. Press the key need to learn from N-2013L , and don't

release that key.

4. Press the accrodng key from Set-up Box original remote,

LED flash quickly then keep lighting when you release

all the keys.

5. Keep going to learn other key.

6. When finished the learning, press HOME to exit and

save.

E. Warm tips

* Pressing and holding BACK key can exit all the menu interface.

(EN)

SMART TV MAGIC REMOTE

Simply Click, Point, scroll to change the channel, search for something new and more. The Magic remote N-2013L can also be used to operate your connected devices. Spend less time navigating confusing menus and juggling multiple remotes, and more time enjoying your entertainment.

N-2013L

A. Register the remote

1. Press the "WHEEL(OK)" (⊕) "about 3 seconds, LED will be light on (Need remote control as close to TV USB interface as possible)

2. Plug the USB receiver into TV's USB port, connection image is appeared on the screen.

3. Point the remote at the USB receiver, LED will flash 3 times and then goes off, registration is completed, pointer is appeared on the screen.

When registration is completed, DIRECTION KEYS (UP/DOWN/LEFT/RIGHT), SCROLL UP, SCROLL, DOWN, WHEEL(OK), Q.SETTINGS, POINTER

*KEY are use RF, but other function key still retain to use IR.

*With few TV sets, if there is no response when plug into a USB port, please try

another USB ports.

*It is a substitute product which is without voice function.

*It can use for most of smart tv, only a few function can not match.

B. About Pointer

If you press DIRECTION KEYS (UP/DOWN/LEFT/ RIGHT) <><><>

while the pointer is in use, the pointer will disappear from the screen. To

display the pointer on the screen again, press the POINTER KEY <▶ " You

can shake the remote slightly to the right and left to control the direction.

C. Register the remote

Press and hold the "HOME" <⌂> and "BACK" <↶> "KEY at the same time about 5

seconds to unpair the remote with your TV, LED will flash 3 times and then goes

off. Magic Remote will operate like a general IR remote control.

2.4G LG Compatible Type List:

- AN-MR600 AKB74495301
- AN-MR600 AKB74855401
- AN-MR650
- AN-MR650A
- AN-MR700 ...

UNIVERSAL FOR SMART MODEL



USB RECEIVER



SMART TV MAGIC REMOTE

N-2013L

